

ACCESSORIES AND SPARE PARTS



KIT N° ITEMS CODE DESCRIPTION SUITABLE FOR PRODUCTS NOTE

ACCESSORIES AND SPARE PARTS FOR SOLENOID VALVES

	008217	Yellow nut for fixing coil	All the solenoid valves	
	008218	Black screw for fixing coil	All the solenoid valves	
	008229	O Ring for yellow nut	All the solenoid valves	
	004238	O Ring under coil	All the solenoid valves	
G9150/R06	200193	Bracket	N.C.and N.O. solenoid valves type: 1020/..; 1028/..; 1064/..; 1068/..; 1070/4 - /5; 1078/4 - /5 - /M12; 1079/7;	
	009060	Screw	1164/..; 1168/..; 1170/4 - /5; 1178/4 - /5 - /M12; 1512/..; 1522/..; 1132/03 - /04	
9150/R07	008323	Plunger	N.C. solenoid valves type:	
	200292	Plunger spring	1020/..; 1028/..	
	004254	Nut/body O Ring		
9150/R08	008323	Plunger	N.C. solenoid valves type:	Diaphragm pilot
	200292	Plunger spring	1064/..; 1068/..	operated spare parts for:
	200646	Diaphragm	1098/9; 1099/11	1098/9; 1099/11;
	004259	Nut/body O Ring	1078/11; 1079/13 - /M42	1078/11; 1079/13 - /M42
9150/R09	008323	Plunger	N.C. solenoid valves type:	
	200292	Plunger spring	1070/4 - /5; 1078/4 - /5 - /M12;	
	200502	Diaphragm	1079/7	
	004257	Cover/body O Ring		
	004298	Cover/body screws		
9150/R10	008323	Plunger	N.C. solenoid valves type:	Valves out of stock
	004571	Plunger spring	1070/6; 1078/6 - /7; 1079/9	
	200431	Diaphragm		
	004266	Cover/body O Ring		
	004299	Cover/body screws		
9150/R38	008323	Plunger	N.C. solenoid valves type:	
	004571	Plunger spring	1090/5 - /6; 1098/5 - /6 - /7; 1099/9	
	008796	Diaphragm		
	004251	Cover/body O Ring		
	004625	Cover/body screws		
9150/R50	008323	Plunger	N.C. solenoid valves type:	
	004571	Plunger spring	1050/5 - /6; 1058/5 - /6 - /7; 1059/9	
	009278	Piston		
	009277	Piston ring		
	004251	Cover/body O Ring		
	004625	Cover/body screws		
9150/R11	008323	Plunger	N.C. solenoid valves type:	
	200292	Plunger spring	1078/9; 1079/11	
	004118	Diaphragm		
	004253	Cover/body O Ring		
	004256	Pilot O Ring		
	004254	Nut/cover O Ring		
	004692	Cover/body screws		
9150/R43	008387	Piston	N.C.and N.O. solenoid valves type:	Main piston pilot
	008415	Piston ring	1098/9; 1099/11	operated spare parts
	008393	Piston spring	1198/9	
	004251	Cover/body O Ring		
	008966	New pilot O Ring		
	004256	Old pilot O Ring		
	004692	Cover/body screws		

KIT N°	ITEMS CODE	DESCRIPTION	SUITABLE FOR PRODUCTS	NOTE
ACCESSORIES AND SPARE PARTS FOR SOLENOID VALVES				
9150/R39	008387	Piston	N.C.and N.O. solenoid valves type:	Main piston pilot
	008415	Piston ring	1078/11; 1079/13 - /M42	operated spare parts
	008393	Piston spring	1178/11	
	004691	Cover/body O Ring		
	008966	New pilot O Ring		
	004256	Old pilot O Ring		
	004692	Cover/body screws		
9150/R35	N.D.	Pre-assembled armature with nuts	N.O. solenoid valves type:	Diaphragm pilot
	200646	Diaphragm	1164/..; 1168/..	operated spare parts for:
	004259	Nut/body O Ring	1198/9	1198/9
	004238	O Ring under coil	1178/11	1178/11
9150/R34	008757	N.O. armature group	N.O. solenoid valves type:	
	200502	Diaphragm	1170/4- /5; 1178/4 - /5 - /M12	
	004257	Cover/body O Ring		
	004254	Nut/cover O Ring		
	004238	O Ring under coil		
	004298	Cover/body screws		
9150/R40	008757	N.O. armature group	N.O. solenoid valves type:	
	008796	Diaphragm	1190/5 - /6; 1198/5 - /6 - /7	
	004251	Cover/body O Ring		
	004254	Nut/cover O Ring		
	004238	O Ring under coil		
	004625	Cover/body screws		
9150/R51	008757	N.O. armature group	N.O. solenoid valves type:	
	009278	Piston	1150/5 - /6; 1158/5 - /6 - /7	
	009277	Piston ring		
	004251	Cover/body O Ring		
	004254	Nut/cover O Ring		
	004238	O Ring under coil		
	004625	Cover/body screws		
9150/R42	008757	N.O. armature group	N.O. solenoid valves type:	
	004118	Diaphragm	1178/9	
	004253	Cover/body O Ring		
	004256	Pilot O Ring		
	004254	Nut/cover O Ring		
	004238	O Ring under coil		
	004692	Cover/body screws		
9150/R15	200581	Plunger	Solenoid valves for different fluids type:	
	200292	Plunger spring	1512/..	
	004242	Nut/body O Ring	1522/..	
9150/R12	200581	Plunger	Solenoid valves for different fluids type:	
	200292	Plunger spring	1132/03 - /04	
	200520	Diaphragm		
	004244	Cover/body O Ring		
	004298	Cover/body screws		
9150/R13	200581	Plunger	Solenoid valves for different fluids type:	
	200292	Plunger spring	1132/06 - /08	
	004617	Diaphragm		
	004625	Cover/body screws		
9150/R14	200581	Plunger	Solenoid valves for different fluids type:	
	200292	Plunger spring	1142/010 - /012	
	200552	Diaphragm		
	004246	No 2 pilot O Rings		
	004242	Nut/cover O Ring		
	004309	Cover/body screws		

KIT N° ITEMS CODE DESCRIPTION SUITABLE FOR PRODUCTS NOTE

ACCESSORIES AND SPARE PARTS FOR CHECK VALVES

9150/R16	003558	Piston	Check valves type:	Valves on the point of going out of stock
	001869	Spring	3120/7 - /9 - /M22 - /M28	
	004251	Cover/body O Ring	3140/7 - /9 - /M28	
	004299	Cover/body screws	3180/7 - /9 - /M28	
9150/R17	003559	Piston	Check valves type:	Valves on the point of going out of stock
	000728	Spring	3120/11	
	004691	Cover/body O Ring	3140/11	
	004549	Cover/body screws	3180/11	
9150/R18	003854	Piston	Check valves type:	Valves on the point of going out of stock
	000728	Spring	3120/13 - /M42	
	008002	Cover/body O Ring	3140/13 - /M42	
	004302	Cover/body screws		
9150/R19	003855	Piston	Check valves type:	Valves on the point of going out of stock
	001857	Spring	3120/17	
	004261	Cover/body O Ring	3140/17 - /21 - /25	
	004302	Cover/body screws	3160/17; 3180/13 - /M42 - /17	
9150/R52	003558	Piston	Check valves type:	
	001869	Spring	3122/7 - /9 - /M22 - /M28	
	008863	Cover/body gasket	3142/7 - /9 - /M28	
	004299	Cover/body screws	3182/7 - /9 - /M28	
9150/R53	003559	Piston	Check valves type:	
	000728	Spring	3122/11	
	009174	Cover/body gasket	3142/11	
	004549	Cover/body screws	3182/11	
9150/R54	003854	Piston	Check valves type:	
	000728	Spring	3122/13 - /M42	
	009175	Cover/body gasket	3142/13 - /M42	
	004302	Cover/body screws		
9150/R55	003855	Piston	Check valves type:	
	001857	Spring	3122/17	
	009176	Cover/body gasket	3142/17 - /21 - /25	
	004302	Cover/body screws	3182/13 - /M42 - /17	

ACCESSORIES AND SPARE PARTS FOR INDICATORS

9150/R20	003575	Nut	Liquid indicators type:	
	007779	Protection cap	3610/..; 3640/..; 3650/..	
	004259	Nut/body O Ring		
9150/R21	004270	Pre-assembled nut	Moisture - liquid indicators type:	
	007780	Protection cap	3710/..; 3740/..; 3750/..; 3770/..;	
	004259	Nut/body O Ring	3780/..	

KIT N° ITEMS CODE DESCRIPTION SUITABLE FOR PRODUCTS NOTE

ACCESSORIES AND SPARE PARTS FOR FILTERS

G9150/R05	8354/22	Access fitting	Filters with replaceable block type:	
	8392/A	Cap with gasket	4411/..; 4412/..; 4413/..; 4414/..	
	8394/B	Valve core	4421/..; 4413/..; 4414/..	
	003319	Spring	All the filters series 44	
	003322	Flange gasket	Filters with replaceable block type: 4411/..; 4412/..; 4413/..; 4414/..	
	003323	Dehydrating block cover	Filters with replaceable block type:	
	003324	Dehydrating block bottom	4411/..A; 4412/..A; 4413/..A; 4414/..A	
	003936	Screw for filtering tube		
	007677	Filtering tube		
	005535	Mechanical block cover	Filters with replaceable block type:	
	004592	Mechanical block bottom	4411/..C	
	008336	Flange gasket	Filters with replaceable block type: 4421/..; 4423/..; 4424/..	
	008304	Dehydrating block cover	Filters with replaceable block type:	
	008305	Dehydrating block bottom	4421/..A; 4423/..A; 4424/..A	
	008307	Screw for filtering tube		
	008403	Filtering tube	Filters with replac. block type: 4421/..A	
	008345	Filtering tube	Filters with replac. block type: 4423/..A	
	008344	Filtering tube	Filters with replac. block type: 4424/..A	
	008303	Mechanical block cover	Filters with replac. block type:	
	008306	Mechanical block bottom	4421/..C	

ACCESSORIES AND SPARE PARTS FOR OIL SEPARATORS

	5590/5	Pair of connections 5/8" ODS	Oil separators type 5520/C	To be ordered separately
	5590/7	Pair of connections 7/8" ODS		
	003879	Connection gasket		
	5590/9	Pair of connections 1.1/8" ODS	Oil separators type 5520/D	To be ordered separately
	5590/11	Pair of connections 1.3/8" ODS		
	003870	Connection gasket		
	5590/13	Pair of connections 1.5/8" ODS	Oil separators type 5520/E	To be ordered separately
	5590/M42	Pair of connections M42 ODS		
	003965	Connection gasket		
	003322	Flange gasket	Oil separators type 5520/.	

KIT N°	ITEMS CODE	DESCRIPTION	SUITABLE FOR PRODUCTS	NOTE
--------	------------	-------------	-----------------------	------

ACCESSORIES AND SPARE PARTS FOR CHANGEOVER VALVES

9150/R24	004297	Gland	All the changeover devices type
	004329	Gland seal gaskets	3032/..
	004330	Gland seal gaskets	
	004348	Washer	
	3039/44	Pair of connections 1/2"NPT female	Changeover valve 3032/44
	004260	Connection/body O Ring	
	009036	Cap	
	008281	Cap	Changeover valve 3032/64 - /66

ACCESSORIES AND SPARE PARTS FOR BALL SHUT-OFF VALVES

	009035	Cap	Ball shut-off valves 3033/..
	009256	Cap	Ball shut-off valves 3063/44

ACCESSORIES AND SPARE PARTS FOR HERMETIC VALVES

9150/R23	003664	Gland	All the hermetic valves type:
	000384	Gland seal gaskets	6010/..; 6012/..; 6020/..; 6060/..;
	000957	Gland seal gaskets	6070/..
	000382	Washer	
	007486	Cap	
	000913	Spindle	Hermetic valves type 6010/2; 6012/22
G9150/R33	004307	Screw	Hermetic valves type 6020/..
	004326	Spring washer	

ACCESSORIES AND SPARE PARTS FOR RECEIVER VALVES

9150/R23	003664	Gland	Receiver valves type:
	000384	Gland seal gaskets	6110/21 - /22 - /23 - /32 - /33
	000957	Gland seal gaskets	6120/22 - /23 - /33
	000382	Washer	6132/..
	007486	Cap	6140/22 - /23
	000913	Spindle	Receiver valves type: 6110/21 - /22; 6120/22; 6140/22 - /23
	001641	Spindle	Receiver valves type: 6110/23 - /32 - /33; 6120/23 - /33
	9150/R24	004297	Gland
004329		Gland seal gaskets	6110/43 - /44 - /54
004330		Gland seal gaskets	6120/43 - /44 - /54
004348		Washer	
009036		Cap	
001647		Spindle	
9150/R25	000529	Gland	Receiver valves type:
	000534	Gland seal gaskets	6110/66
	000535	Gland seal gaskets	6120/66
	001039	Washer	
	008282	Cap	
	001038	Spindle	

KIT N°	ITEMS CODE	DESCRIPTION	SUITABLE FOR PRODUCTS	NOTE
--------	------------	-------------	-----------------------	------

ACCESSORIES AND SPARE PARTS FOR STOP VALVES

9150/R26	000822	Gland	Stop valves type: 6170/66 - /77
	000823	Gland seal gaskets	
	000824	Gland seal gaskets	
	007476	Washer	

ACCESSORIES AND SPARE PARTS FOR ROTALOCK VALVES

9150/R23	003664	Gland	Rotalock valves types: 6310/.. 6320/..	To be ordered separately
	000384	Gland seal gaskets		
	000957	Gland seal gaskets		
	000382	Washer		
	7910/6	Steel solder connection 3/4" UNF-16		
	7990/6	PTFE gasket for 7910/6		
	7910/8	Steel solder connection 1" UNS-16		
	7990/8	PTFE gasket for 7910/8		

ACCESSORIES AND SPARE PARTS FOR CAPPED VALVES

9150/R23	003664	Gland	Capped valves type: 6410/..; 6420/..; 6460/..
	000384	Gland seal gaskets	
	000957	Gland seal gaskets	
	000382	Washer	
	007486	Cap	
	002337	Spindle	Capped valves type: 6410/2 - /3 - /4 - /5 6420/2 - /3 - /M10 - /M12 - /4 - /5 6460/22A.
	005174	Nipple/body O Ring	
	007619	Spindle	Capped valves type: 6410/6 6420/M18 - /6 - /M22 - /7
	007676	Nipple/body O Ring	

KIT N° ITEMS CODE DESCRIPTION SUITABLE FOR PRODUCTS NOTE

ACCESSORIES AND SPARE PARTS FOR GLOBE VALVES

9150/R24	004297	Gland	Globe valves type:
	004329	Gland seal gaskets	6510/M22 - /7 - /M28 - /9 - /11
	004330	Gland seal gaskets	6520/7 - /9 - /11
	004348	Washer	6530/M22 - /7 - /M28 - /9 - /11
	001635	Cap	6532/M22 - /7 - /M28 - /9 - /11
	004296	Cap gasket	
9150/R27	007637	Spindle/plate group	Globe valves type: 6510/M22 - /7 - /M28 - /9; 6520/7 - /9
	004299	Cover/body screws	6530/M22 - /7 - /M28 - /9 6532/M22 - /7 - /M28 - /9
	004251	Cover/body O Ring	Globe valves type: 6510/M22 - /7 - /M28 - /9; 6520/7 - /9 6530/M22 - /7 - /M28 - /9
	008863	Cover/body gasket	Globe valves type: 6532/M22 - /7 - /M28 - /9
	007638	Spindle/plate group	Globe valves type:
9150/R28	004692	Cover/body screws	6510/11; 6520/11; 6530/11; 6532/11
	004291	Cover/body O Ring	Globe valves type: 6510/11; 6520/11; 6530/11
	009174	Cover/body gasket	Globe valves type: 6532/11
	000822	Gland	Globe valves type:
9150/R26	000823	Gland seal gaskets	6510/13 - /M42 - /17
	000824	Gland seal gaskets	6520/13 - /M42 - /17
	007476	Washer	6530/13 - /M42 - /17
	001228	Cap	6532/13 - /M42 - /17
	000830	Cap gasket	
	004302	Cover/body screws	
9150/R29	007639	Spindle/plate group	Globe valves type:
	008002	Cover/body O Ring	6510/13 - /M42; 6520/13 - /M42
9150/R30	007640	Spindle/plate group	Globe valves type: 6510/17; 6520/17 6530/13 - /M42 - /17 6532/13 - /M42 - /17
	004261	Cover/body O Ring	Globe valves type: 6510/17; 6520/17 6530/13 - /M42 - /17
	009176	Cover/body gasket	Globe valves type: 6532/13 - /M42 - /17

KIT N°	ITEMS CODE	DESCRIPTION	SUITABLE FOR PRODUCTS	NOTE
--------	------------	-------------	-----------------------	------

ACCESSORIES AND SPARE PARTS FOR BALL VALVES

	009055	Cap	Ball valves type: 6590/M6 - /2 - /3 - /3A - /M10 - /M10A - /M12 - /M12A - /4 - /4A 6591/5 6590/M15 - M15A - /5 - /5A - /M18 - /M18A - /6 - /6A 6591/7	
	009036	Cap	Ball valves type: 6590/7 - /7A 6591/M28 - /9 6590/M28 - /M28A - /9 - /9A 6591/11	
	009037	Cap	Ball valves type: 6590/11 - /11A 6591/13 - /M42 6590/13 - /13A - /M42 - /M42A 6591/17	
	009038	Cap	Ball valves type: 6590/17 - /17A 6591/21 - /21A	
	009207	Cap	Ball valves type: 6590/M64A - /21A	
	009208	Gasket	6591/24A - /25A	
G9150/R46	8394/A	Valve core	Ball valves with access fitting	
	8392/A	Cap with gasket		

ACCESSORIES AND SPARE PARTS FOR COMPRESSOR VALVES

9150/R23	003664	Gland	Compressor valves type 6640	
	000384	Gland seal gaskets		
	000957	Gland seal gaskets		
	000382	Washer		

ACCESSORIES AND SPARE PARTS FOR GAUGE MOUNTING VALVES

9150/R23	003664	Gland	Gauge mounting valves	
	000384	Gland seal gaskets	8320/21 - /22	
	000957	Gland seal gaskets		
	000382	Washer		

